

Značka	Model	CC	Rok	Přední	Zadní
HUSQVARNA	125 CR	125	00-03	DF635	DF885
HUSQVARNA	125 CR	125	04-04	DF635	DF885
HUSQVARNA	125 SM S	125	00-	DF635	DF885
HUSQVARNA	125 SM S 4T	125	11-	DF635	DF885
HUSQVARNA	125 TE 4T	125	11-13	DF635	DF885
HUSQVARNA	125 WR	125	00-05	DF635	DF885
HUSQVARNA	125 WRE	125	00-	DF635	DF885
HUSQVARNA	250 CR	250	00-03	DF635	DF885
HUSQVARNA	250 CR	250	04-04	DF635	DF885
HUSQVARNA	250 TC	250	04-04	DF635	DF885
HUSQVARNA	250 TE	250	05-	DF635	DF885
HUSQVARNA	250 TE R	250	13-13	DF635	DF885
HUSQVARNA	250 WR	250	00-	DF635	DF885
HUSQVARNA	300 WR	300	09-	DF635	DF885
HUSQVARNA	360 WR	360	00-	DF635	DF885
HUSQVARNA	450 SM / RR	450	06-	DF645	DF885
HUSQVARNA	450 SM R	450	01-04	DF645	DF885
HUSQVARNA	450 SM R	450	05-05	DF645	DF885
HUSQVARNA	450 SM S	450	01-04	DF645	DF885
HUSQVARNA	510 SM R	510	05-05	DF645	DF885
HUSQVARNA	510 SM R	510	06-	DF645	DF885
HUSQVARNA	510 TC	510	04-04	DF635	DF885
HUSQVARNA	510 TE	510	00-04	DF635	DF885
HUSQVARNA	570 SM R	570	01-	DF645	DF885
HUSQVARNA	570 SM S	570	01-	DF645	DF885
HUSQVARNA	570 TE	570	00-	DF635	DF885
HUSQVARNA	610 SM ie	610	07-	DF645	DF885
HUSQVARNA	610 SM R	610	00-04	DF645	DF885
HUSQVARNA	610 SM R	610	05-05	DF645	DF885
HUSQVARNA	610 SM R	610	06-	DF645	DF885
HUSQVARNA	610 SM S	610	00-04	DF645	DF885
HUSQVARNA	610 TC	610	00-	DF635	DF885
HUSQVARNA	610 TE	610	00-	DF635	DF885
HUSQVARNA	610LT	610	00-	DF645	DF885
HUSQVARNA	630 SMR	630	06-	DF645	DF885
HUSQVARNA	630 TE	630	10-	DF635	DF885
HUSQVARNA	NOX	600	01-	DF645	DF885
HUSQVARNA	STR 650 CRC	650	07-	DF645	DF885
HUSQVARNA	TC 449	450	11-	DF635	DF885
HUSQVARNA	TE 410/E	410	00-	DF635	DF885
HUSQVARNA	TE 449	450	11-	DF635	DF885
HUSQVARNA	TE 511	511	11-	DF635	DF885
SWM	GRAN MILANO	440	16-		DF885

SWM	RS 650 R	650	16-	DF635	DF885
SWM	SILVER VASE	440	16-		DF885
SWM	SUPER DUAL	650	16-	DF645	DF885